

Power Brake Units

BENDIX SINGLE DIAPHRAGM

Chevrolet
Dodge
Ford
GMC
International Harvester
Jeep

DESCRIPTION

Vacuum suspended, self-contained, vacuum-hydraulic unit which utilizes engine manifold vacuum and atmospheric pressure to provide its power. Vacuum power unit contains power piston assembly, which houses control valve, reaction mechanism, and return spring. Control valve consists of air valve, floating control valve assembly, and push rod. Reaction mechanism consists of reaction plate and levers. A vacuum check valve is mounted in front housing for connection to vacuum source.

REMOVAL & INSTALLATION

NOTE — Power brake unit can be removed without removing master cylinder or disconnecting hydraulic lines on Chevrolet, Ford and GMC models. Master cylinder must be removed on Dodge, IHC, Jeep and Plymouth models.

Removal — Disconnect vacuum line from power unit. Remove hydraulic lines from master cylinder. Disconnect pedal linkage and remove bolts holding power unit to firewall. Remove power unit from vehicle.

Installation — Reverse removal procedure, noting the following: Before attaching master cylinder, check push rod for proper length. See *Push Rod Adjustment*. If hydraulic lines were disconnected, bleed system before moving vehicle.

OVERHAUL

NOTE — Only Chevrolet and GMC recommend overhaul of power brake unit.

Disassembly — 1) Scribe mark housings for reassembly. Remove master cylinder from power unit and set aside. Remove front housing seal and piston rod. Attach assembly to suitable holding fixture (J-22805). **CAUTION** — Ensure proper tool alignment to avoid damage to check valve in front housing. Loosen lock nut and remove push rod clevis and lock nut, if

equipped. Remove dust boot retainer, dust boot, and silencer from diaphragm plate extension. Partially straighten four deepest tabs on rear housing. Place suitable wrench (J-9504) over studs on rear housing and attach with nuts and washers. Press down on wrench and rotate rear housing clockwise to separate. **CAUTION** — Housings are under internal spring tension. Remove wrench from housing.

2) Remove air filter from diaphragm plate extension. Remove diaphragm from groove in diaphragm plate. **CAUTION** — Protect and handle diaphragm carefully. Hold diaphragm plate so that push rod is in horizontal position. Depress rod slightly and rotate piston until air valve lock falls from diaphragm plate hub. Remove reaction disc from diaphragm plate bore (use push rod, or suitable tool, to push disc from seat). **CAUTION** — Do not chip diaphragm plate.

3) Remove rear shell bearing seal with punch or screwdriver. **CAUTION** — Remove seal only if new one is available. Do not reuse seal if it has been removed. Remove vacuum check valve and grommet.

Cleaning & Inspection — Use only denatured alcohol to clean all metal, plastic, and rubber parts. Blow out all passages, orifices, and valve holes with clean, dry air, and air dry all parts. Slight rust on inside of housing can be polished with crocus cloth or fine emery cloth. There should be no cuts, nicks, or distortion of any rubber part. If in doubt about condition of any part, replace part.

Reassembly — 1) Install vacuum check valve grommet (beveled edge on inside), dip check valve in clean, denatured alcohol and install. Install suitable holding fixture (J-22805) on front housing. Install new rear housing seal in center hole, using suitable tool (J-22677) to seat seal in recess (tool bottoms against housing when seal is in place).

2) Assemble diaphragm plate assembly as follows: Lubricate outer diameter of diaphragm plate and extension, valve, and plunger bearing surfaces, and outer edge of valve poppet. Install valve and rod into diaphragm plate extension. Depress push rod slightly and install air valve lock (lock must index and retain air valve). Install rolling diaphragm in diaphragm plate hub groove. Lubricate reaction disc and install disc (use master cylinder push rod to seat disc in diaphragm plate bore). If disc is not fully seated, push rod height will be gauged incorrectly during adjustment procedure.




Fig. 1 Exploded View of Bendix Single Diaphragm Assembly

BENDIX SINGLE DIAPHRAGM (Cont.)

3) Lubricate inside of bearing seal and diaphragm bead contact-surface of rear shell. Install diaphragm plate assembly in rear housing. Place air filter element over push rod and into diaphragm plate extension. Install filter retainer. With holding-fixture in place, position suitable wrench (J-9504) over studs on rear housing and position front and rear housings together. Press down on wrench and rotate counterclockwise (rear housing) to lock housings. Align scribe marks. Rebend tabs on rear housing (if tabs are cracked or broken, housing must be replaced). Remove wrench from housing. Install air silencers over push rod end. Install push rod boot and boot retainer. On clevis-type push rods, install lock nut and push rod clevis. Lightly lubricate piston rod (except rounded end). Guide rod into center bore until fully seated against reaction disc. Install front housing seal (in same manner as rear seal). Attach master cylinder.

3) To verify correct adjustment, sight through rear port of master cylinder when attaching to power unit. Master cylinder piston should not move as it contacts push rod. Maximum allowable movement is .015".

ADJUSTMENTS

PUSH ROD ADJUSTMENT

1) Push rod height check or adjustment is required if master cylinder and power unit are separated, or if push rod is replaced or transferred from one unit to another, or if misadjustment is diagnosed as cause of braking problems.

2) Place gauge over push rod and adjust push rod nut to provide a slight tension (approx. 5 lbs.) against gauge. See *Push Rod Height chart and Push Rod Gauge Dimensions to fabricate suitable gauge.*




Fig. 3 Using Gauge to Measure Push Rod Protrusion




Fig. 2 Push Rod Dimensions

PUSH ROD HEIGHT

Application	Dimension "A"
Chevrolet	⓪
Dodge	⓪
Ford880-.895"
GMC	⓪
IHC	
W/Drum Brakes980-.995"
W/Disc Brakes	1.185-1.200"
Jeep	⓪

⓪ - Non-adjustable.