

# Drive Axles

## FORD SEPARATE HOUSING

**Bronco, E100/150, F100/150**  
Rear Axle

### DESCRIPTION


The axle is a banjo-type housing with a removable carrier. Drive pinion is straddle-mounted, and pinion depth is adjusted by shims. Ring gear and differential case are mounted on the removable carrier.

Preload on side bearings is set by adjusting nuts on which bearing cups rest. Its removable carrier and its lack of a rear cover plate help distinguish this unit from Dana (Spicer) units. It is used with semi-floating axles in all applications. Ring gear diameter is 9.0" (228.6 mm).

### AXLE RATIO & IDENTIFICATION

Axle ratio and model identification numbers may be found on the metal tag, attached to axle by 1 carrier bolt. Other information on tag includes date code, ring gear diameter and assembly plant code. The information on this tag must be used to order replacement parts.

**Fig. 1: Ford Drive Axle Identification Tag**



Use information on tag to order replacement parts.

### REMOVAL & INSTALLATION

#### AXLE SHAFTS

##### Models With Ball Type Bearing

1) Remove wheels and brake drums. Working through hole in axle flange, remove 4 wheel bearing retainer nuts. Using a slide hammer connected to axle, pull out axle and bearing. Remove backing plate, and suspend from frame with wire. Replace oil seal, using seal remover (1175-AC) and slide hammer.

2) To install, reverse procedure. Use new bearing retainer gasket. Make sure bearing is firmly seated in axle housing.

##### Models With Tapered Roller Bearing

Follow same procedure as outlined for ball bearing removal. Use a slide hammer to remove bearing cup from axle housing. To install, reverse removal procedure. Place bearing cup over tapered bearing, before sliding axle into housing.

**NOTE:** If axle is removed for service or overhaul, a new oil seal must be installed.

#### AXLE BEARINGS & SEALS

##### Models With Ball Type Bearing

1) With axle removed, drill a 1/4-1/2" (6-12 mm) hole in bearing retainer ring. Drill hole to a depth of 3/4 the thickness of retainer ring. Do not drill through ring into axle shaft.

2) Place a chisel across drilled hole. Strike with a hammer until ring separates. Remove ring, and press bearing from axle shaft using a press and axle bearing plate (T75L-1165-B). Press a new bearing and retainer onto axle shaft. Drive new seal into axle housing. Do not attempt to press new bearing and retaining ring onto axle at the same time.

##### Models With Tapered Roller Bearing

1) With axle removed, drill a 1/4-1/2" (6-12 mm) hole in bearing retainer ring. Drill hole to a depth of 3/4 the thickness of retainer ring. Do not drill through ring into axle shaft.

2) Place a chisel across drilled hole. Strike with a hammer until ring separates and can be removed. Remove bearing cup from housing and place over bearing.

3) Place removal collet (T75L-1165A, B or C, or equivalent) over bearing. Place axle shaft in press, position over a support plate and press off bearing.

**NOTE:** If removal collet is not used, bearing must be discarded.

4) Install retainer plate on axle shaft (if removed). Lubricate new seal and bearing. Place seal and bearing on axle, making sure cup rib ring is facing axle flange.

5) Press bearing onto axle, making sure that it is fully seated. Do not attempt to press bearing retainer on at the same time. Press on a new bearing retainer.

#### PINION FLANGE & SEAL

##### Removal

1) Mark propeller shaft end yoke and pinion flange for reassembly reference. Disconnect propeller shaft, and tie out of way. Scribe marks on pinion shaft and pinion flange for reassembly reference.

2) Measure and record pinion bearing preload. Remove pinion nut, washer and flange. Remove oil seal with slide hammer and seal remover.

##### Installation

1) Press new oil seal into bore in bearing retainer, and seal outer edge with oil resistant sealer. Install pinion flange, washer and new nut. Tighten pinion shaft nut slowly, while rotating pinion flange to insure proper seating of pinion bearings.

2) Continue tightening nut, taking frequent preload readings. If recorded preload reading was less than specifications, tighten to specifications. If recorded reading was more than specification, tighten to original reading.


3) Install drive shaft. Do not back off pinion nut to lessen preload. If backed off, a new spacer must be installed.

#### DIFFERENTIAL CARRIER

Remove both axle shafts. Mark propeller shaft end yoke and pinion flange for reassembly reference. Remove propeller shaft. Drain rear axle lubricant. Remove

## FORD SEPARATE HOUSING (Cont.)

Fig. 2: Exploded View of Ford Separate Housing Drive Axle



Banjo-type differential is used on these drive axles.

carrier attaching bolts and differential carrier. To install, reverse removal procedure.

### OVERHAUL DISASSEMBLY

1) Mark differential bearing caps for reassembly reference. Remove adjusting nuts, and remove differential case from carrier. Remove differential side bearings from case. Remove ring gear attaching bolts and discard. Tap ring gear from case, using a soft faced hammer.

2) Drive out differential pinion shaft retaining pin. Mark case halves for reassembly reference, and separate case. Using brass drift, drive out pinion shaft. Remove differential side gears, pinion gears, and thrust washers from case.

3) Remove pinion shaft nut, washer, pinion flange, and seal from carrier. Remove pinion shaft and bearing retainer, noting number and thickness of shims between retainer and carrier. Remove straddle bearing and retainer from carrier, using driver. Press pinion bearings from pinion shaft. Press bearing cups from bearing retainer.

### REASSEMBLY & ADJUSTMENT

**NOTE:** Lubricate all parts with hypoid gear lubricant during assembly.

#### Differential Case Assembly

1) Place differential side gear and thrust washer into differential case bore. From outside of case, drive differential pinion shaft into case, just far enough to retain pinion thrust washer and pinion gear. Place second pinion thrust washer and gear into position in case.

2) Drive pinion shaft into place, making sure shaft retainer holes are in alignment with holes in case. Install second side gear and thrust washer. Assemble case halves, and install retainer pin. Install differential side bearings and ring gear, and tighten ring gear bolts to specifications.

**NOTE:** Ring and pinion gears should not be used if numbers do not match.

#### Drive Pinion Depth

1) Press new pinion bearing cups into pinion retainer housing until fully seated, making sure a .0015" (.038 mm) feeler gauge cannot be inserted between bearing cup and bottom of bore.

2) Install new straddle bearing and retainer (with concave side up) in carrier. Fully seat bearing and retainer. Press rear pinion bearing onto pinion shaft.

3) Determine pinion shim thickness by performing the following steps:

- If same ring and pinion gears are being reused, install original shim pack.
- If new ring and pinion gears are being installed, use "nominal" thickness shim, and make tooth contact pattern to see if additional shims are required.

4) Adjust pinion depth using rear axle pinion depth gauge (T79P-4020-A or equivalent) as follows:

- Assemble aligning adapter and gauge disc over threaded shaft.
- Install gauge block on threaded shaft, and tighten securely.
- Insert gauge assembly and new rear pinion bearing into pinion bearing retainer assembly.
- Install front pinion bearing. Install handle on tool assembly with tapered end in front pinion bearing.

# Drive Axles


## FORD SEPARATE HOUSING (Cont.)

5) Install pinion bearing retainer and gauge assembly into carrier (without a pinion shim). Tighten retainer assembly mounting bolts to 30-45 ft. lbs. (41-61 N.m). Rotate gauge block so it rests against pilot boss. Install gauge tube in differential bearing bore. Install and tighten bearing cap and bolts. See Fig. 3.

6) Using a feeler gauge, select the thickest blade that will enter between gauge block and gauge tube. See Fig. 3. Insert feeler blade directly along top of gauge block to insure a correct reading. The fit should provide a slight drag.

7) Select correct shim to be inserted, by comparing feeler gauge thickness with shim requirement in Shim Chart. Remove assembly and install drive pinion and ring gear.

**Fig. 3: Measuring Ford Pinion Depth With Gauge (T79P-4020-A)**



Using feeler gauge, measure pinion depth.

### Pinion Bearing Preload (With Collapsible Preload Spacer)

1) Place new preload spacer on drive pinion shaft. Install front pinion bearing and bearing retainer. Press bearing into position, being careful not to crush spacer. Install "O" ring in groove in bearing retainer, and place selected pinion depth shim on carrier housing. Install pinion assembly and tighten bolts.

2) Install pinion flange, washer and nut. Tighten pinion flange nut to 175 ft. lbs. (238 N.m). Check pinion bearing preload.

3) Continue to tighten pinion flange nut until proper preload is obtained. Do not exceed 175 ft. lbs. (238 N.m) at this time. Do not back off nut to obtain preload. If torque on pinion shaft is less than 175 ft. lbs. (238 N.m) after preload is set, a new collapsible spacer must be installed.


### Backlash & Side Bearing Preload

1) Place cups on differential side bearings, and set differential case in carrier. Slide assembly along bores until a slight amount of backlash is felt between gear teeth. Set adjusting nuts in bores so nuts just contact bearing cups. Each nut should be engaging approximately the same number of threads.

2) Carefully position bearing caps on carrier, install bearing cap bolts, and tighten to specifications. Make sure adjusting nuts turn freely as bolts are tightened. If not, remove caps and inspect for damaged threads. Loosen cap bolts and retorqued to 25 ft. lbs. (34 N.m).

3) Loosen right adjusting nut until it is away from cup. Tighten left nut until ring gear is just forced into pinion with no backlash. Make sure right nut is still loose. Install dial indicator. See Fig. 4.

**Fig. 4: Adjusting Side Bearing Preload**



Loosen right adjusting nut, and tighten left side.

4) Tighten right nut until it first contacts bearing cup. Continue tightening until side bearing preload (case spread) is to specifications. Turn pinion gear several times in each direction to seat bearings and make sure no binding is evident.

5) Tighten bearing cap bolts to specifications. Install a dial indicator on carrier, so that contact tip of indicator bears against face of gear tooth on outer diameter of ring gear.

6) Measure backlash at several locations on ring gear. If backlash measurements vary more than .004" (.10 mm), there is excessive runout in gear or mounting.

7) If backlash is not correct, loosen 1 adjusting nut and tighten opposite nut an equal amount. This will move ring gear into adjustment. After this procedure, always check case spread specifications.

8) When side bearing preload and ring gear backlash are correctly set, perform gear tooth pattern check, and install carrier into axle housing.

**NOTE:** When moving adjusting nuts, final movement should always be made in a tightening direction. If nut must be loosened 1 notch, loosen 2 notches and then tighten 1 notch.

### TIGHTENING SPECIFICATIONS

Application	Ft. Lbs. (N.m)
Side Bearing Cap Bolts	70-85 (95-115)
Ring Gear Bolts	70-85 (95-115)
Pinion Flange Nut	
Collapsible Spacer (Min.)	175 (238)
Pinion Bearing	
Retainer-to-Carrier	30-45 (41-60)
Carrier-to-Housing	25-40 (34-54)
Adjusting Nut Lock Bolts	12-25 (17-33)
Bearing Retainer Plate Bolt	20-40 (28-54)

## FORD SEPARATE HOUSING (Cont.)

### PINION DEPTH SHIM ADJUSTMENT CHART (INCHES)

Old Pinion Marking	New Pinion Marking								
	-4	-3	-2	-1	0	+1	+2	+3	+4
+4	+0.008	+0.007	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0
+3	+0.007	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001
+2	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002
+1	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003
0	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004
-1	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005
-2	+0.002	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006
-3	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006	-0.007
-4	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006	-0.007	-0.008

### AXLE ASSEMBLY SPECIFICATIONS

Application	Specifications In. (mm)
Ring Gear Backlash .....	.008-.015 (.20-.38)
Ring Gear Runout (Max.) .....	.004 (.10)
Backlash Variation (Max.) .....	.004 (.10)
Side Bearing Preload (Case Spread)	
New Bearings .....	.008-.012 (.20-.30)
Used Bearings .....	.005-.008 (.13-.20)
Side Gear Thrust	
Washer Thickness .....	.030-.032 (.76-.81)
Pinion Gear Thrust	
Washer Thickness .....	.030-.033 (.76-.84)
Nominal Pinion Shim Thickness .....	.015 (.38)
	<b>INCH Lbs. (N.m)</b>
Pinion Bearing Preload (Rotating Torque)	
Collapsible Spacer	
New Bearings .....	8-14 (1.0-1.5)
Used Bearings .....	16-29 (1.8-3.3)