

JEEP

Jeep

FUSE PANEL

All Models – Located under the instrument panel on the driver's side of vehicle.

CIRCUIT BREAKERS

All Models – A 20 ampere circuit breaker protects the lighting system on all vehicles and is built into headlight switch. Cherokee and Wagoneer models equipped with an electric tailgate window have two 30 ampere circuit breakers


located at the fuse panel to protect the electric tailgate regulator motor and wiring harness.

IN-LINE FUSES


All Models – In-line fuses protect circuits for the park brake warning and brake failure system with a 5 ampere fuse. The radio is protected with a 5 ampere fuse in addition to the fuse located in fuse panel.

FUSIBLE LINKS

All Models – A fusible link is located in alternator wiring harness for protection of the system.



"CJ" MODELS FUSE PANEL



ALL MODELS (EXC. "CJ") FUSE PANEL